

REPLACEMENT PARTS GUIDE

5303 and 5403 Tractors (South America Edition)

HYDRAULIC



OIL ELEMENT [RE45864](#)

Replace after first 100 hours then after every 1000 hours.



ENGINE



FUEL FILTER [RE60021](#)

Replace after every 500 hours alternatively.



PRIMARY AIR FILTER [AT171853](#) SECONDARY AIR FILTER [AT171854](#)

Replace after every 1000 hours or annually whichever occurs first. Change as required.



OIL FILTER [T19044](#)

Replace at first 100 hours, Replace every 1000 hours, Replace annually.

CAPACITIES

5303 and 5403 Tractors (South America Edition)

CAPACITIES (Approximate):

Fuel Tank:

..... 68 L (18 gal)

Cooling System:

Cool-Gard™ II

..... 9.5 L (2.08 gal)

Crankcase including Filter Change:

Plus-50™

..... 8.5 L (1.86 gal)

Transmission and Hydraulic System:

Hy-Gard™

..... 38 L (10 gal)

REPLACEMENT PARTS GUIDETIES

5303 and 5403 Tractors (South America Edition)

ENGINE



BRAKE DISK
[AL162808](#)



ALTERNATOR
[RE234714](#) (43 A MICO)



CLUTCH DISK
[SJ29351](#) (TRACTION)
[RE242274](#) (PTO CLUTCH DISK)



BATTERY
[RE208816](#) (WET CHARGED BATTERY)



FAN BELT DRIVE
[R272592](#)



CAB



SEAT
[RE264714](#) (CUSHION) (BACK)
[RE258489](#) (CUSHION) (BOTTOM)

AXLE



TIE ROD
[RE217616](#) (TIE ROD ASSEMBLY)
[RE217817](#) (TIE ROD END)
[RE271437](#) (TIE ROD ASSEMBLY)
[RE271440](#) (TIE ROD END) (BALL JOINT)
[RE271441](#) (TIE ROD END) (90 DEGREES)