

REPLACEMENT PARTS GUIDE

L118 Lawn Tractor with 42 inch Deck

ENGINE

SPARK PLUG

[M78543](#)

Change Every 50/100/150/200/250 Hrs.

ENGINE OIL FILTER

[AM125424](#)

ENGINE OIL

[TY22029](#) (TURF GARD™ 10W30)
(1.8 L (1.9 qt) (WITHOUT FILTER))
(1.9 L (2 qt) (WITH FILTER))

Change Every 50/100/150/200/250 Hrs.

FUEL FILTER-IN-LINE

[AM116304](#)

Change Every 50/100/150/200/250 Hrs.

AIR FILTER

[GY20575](#)

Change Every 50/100/150/200/250 Hrs.

HOME MAINTENANCE KIT

[LG253](#) (FOR USA)

[CXLG230](#) (FOR CANADA)

MULTI-PURPOSE SD POLYUREA GREASE

[TY6341](#)

Change Interval:As needed.

GREASE GUN

[TY26183](#)

FUEL AND AIR

FUEL TANK FILLER CAP

[GX22166](#)

MUFFLER

[GY21132](#)

ELECTRICAL

ROTARY SWITCH

[GY20074](#)

PLUNGER SWITCH

[GY20094](#)

REVERSE IMPLEMENT PUSH SWITCH

[AM124734](#)

TRACTION DRIVE BELT

[UC30568](#) (LGTH = 2258 mm, TK = 12.45 mm,
WIDTH = 12.7 mm)

KEY

[GY20680](#)

BATTERY

[TY25221B](#)

CONTROL LEVER THROTTLE CABLE

[GY20097](#)

HEADLIGHT BULB


[AD2062R](#) (12.8 V)




REPLACEMENT PARTS GUIDE

L118 Lawn Tractor with 42 inch Deck


MOWER DECK


 **MOWER BLADE MULCH**
[GX20433](#) (HIGH LIFT)

 **MOWER DECK LEVELLING GAUGE**
[AM130907](#)



MOWER DECK

 **GAGE WHEEL**
[GX10168](#)

 **FLAT MOWER BELT**
[GX20072](#) (LGTH = 2635 mm,
WIDTH = 12.7 mm, TK = 8.89 mm)